

Rebooting your Robic SC-591 Watch



If something occurs and your Robic SC-591 Watch is not 100% functional or an operation is missing, (for example, a mode will not appear) there is a simple process to reboot your watch to its original settings.

*Take the watch off your wrist.

*Hold it in your hand and depress all four pushbuttons (S1, S2, S3, S4) simultaneously for 3 to 5 seconds with your fingertips.

*Release the buttons by letting go of the buttons all at the same time.

*The watch should now go through a shut down and reboot process where the display will show different segments of the digits.

*After a brief time, the watch will show 12:00:00 AM on the time display...time will begin to count up.

*This means the watch is rebooted and now you can set the time of day, calendar, alarm and Referees Timer, to your desired settings. Mode through each function to ensure all appear on your watch.

Instructions for the Robic SC-591 can be found and downloaded here:

<https://cdn.shopify.com/s/files/1/0522/4749/4813/files/sc591.pdf?v=1616532400>

